

PRODUCT DATA SHEET

ROOF WALKWAY PAD WITH TAPE



Water Tight Technologies, LLC
2500 Dewitt Street
Elkhart, IN 46517
www.watertighttech.com

Description: RUBBERALL® Walkway Pads are high quality EPDM pads designed to protect the field membrane from damage caused by foot traffic at roof access points. They have excellent grip and slip resistance. They resist punctures, tears and resist UV radiation.

Suggested Uses: RUBBERALL® Walkway Pads can be used on roof tops to protect the EPDM roofing from damage due to required foot traffic around HVAC units and other mechanicals which require maintenance service and all high traffic areas.

Sizes: RUBBERALL® Walkway Pads with tape, are 30" x 30" and .375" thick from the bottom of the pad to the top of the button.

Physical Properties

Property Type	Test Method	Specification
Tear Resistance	ASTM D 624	250 lbf / in
Tensile Strength	ASTM D 412	500 PSI
Color		Black

Application Instructions:

1. Remove all dust, talc, dirt and other debris from the membrane surface.
2. Layout the walkway Pads to define the desired traffic pattern and using a crayon or chalk, mark the placement of the pads on the roof membrane. The pads should be laid out with a minimum of 1" and a maximum of 6" space between the pads.
3. Maintain a minimum of 3" space from a field seam. If the walkway Pad must cover a field seam, apply a Cover Tape over the seam before the Walkway Pad is installed.
4. Turn the pads over and clean the existing roof membrane where the tape on the Walkway Pads will bond with the roof membrane using Membrane Cleaner and cotton rags.
5. Using a scrub pad, apply Seam Tape Primer in a circular motion to the cleaned areas of the roof membrane. Do not over apply the primer. It should be evenly applied without puddles or globs resulting in a smooth flat application. Allow the primer to dry or "flash-off".
6. Clean any dust or debris from the Walkway Pad release film and place the pad into position using the crayon marks. Remove the release film and mate the tape adhesive to the primed area of the field membrane.
7. Using a roller with pressure, mate the Walkway Pad adhesive surface to the primed field membrane.

Precautions: Do not install Walkway Pads within 10' of the roof perimeter if avoidable.

Storage: Store in a cool, dry area protected from weather. In hot, sunny weather, store on-site in original boxes in a shaded area, until ready to use.