



Water Tight Technologies, LLC

P.O. 899, Payson, AZ 85547

www.britenez.com

Product Data Sheet

BRITE-n-EZ™ TPO Membrane Self Adhered

.060" (60 mil) and .045" (45 mil)

DESCRIPTION

BRITE-n-EZ™ TPO (Thermoplastic Polyolefin) Membrane (Self Adhered) meets or exceeds all of the requirements for ASTM D6878-03. Membrane is reinforced with a high quality polyester scrim for added strength and stability. Nominal thickness of the membrane is .045 inch (45 mil) thick or .060 inch (60 mil) with .008 inch (8 mils) of self-adhering butyl adhesive on the back. The membrane comes in rolls 5 or 10 feet wide by 50 or 100 feet long. The membrane has a plastic release liner protecting the adhesive until it is time to adhere it to the substrate. This plastic release liner may be recycled when removed from the membrane. The release liner is in two sections so that the liner may be removed from one half at a time as membrane is adhered to the substrate.

MEMBRANE PHYSICAL PROPERTIES

PROPERTY	TEST METHOD (ASTM)	ASTM Minimum	Typical Values for .045
Color			White
Weight—lbs/ft ² (kg/m ²)			
.045"	D-751		.301 lbs
.060"			.365 lbs.
Nominal Thickness – inches (mm)	D-751	.039 (min)	.045
Factory Seam Strength	D-751	66 lbf	66+ lbf (membrane failure)
Breaking Strength	D-751 Grab Method	220 lbf / in.	285 lbf x 245 lbf
Elongation at Break-min %	D-751	15	30
Tear Strength –	D-751 8" x 8" Sample	55 lbf	124 lbf x 140 lbf
Puncture Resistance	FTM 101C Method 2031	Not Established	290 lbs.
Heat Aging	D-573	90% Retention of Breaking Strength and Elongation at Break	100%
Cold Brittleness	D-2137	-40C	-40C
Ozone Resistance –	D-1149	No visible deterioration @ 7x magnification	No visible deterioration @ 7x magnification
Hydrostatic Resistance	D-751 Method D	Not Established	390 psi
Water Absorption – Max mass %	D-471 @158F, 1 week	+/- 3.0% max.	0.7%
Water Vapor Permeance – Perm	E-96	Not established	.070 perms
Linear Dimensional Change – max %	D-1204 @ 158F, 6 hrs.	±1	0.4
Reflectivity: White (%)	C-1549 & E408	N/A	0.76
Emmissivity: White	E903	N/A	0.90

INSTALLATION (MEMBRANE)

Substrates must be clean, dry and free of foreign materials such as grease, oil, debris and other materials which could inhibit adhesion. Temperatures must be 50° F or more to apply Self Adhered membrane. When near (but above) this temperature, rolls should remain in a warm environment until ready to install.

FIRST SHEET:

- Unroll the *BRITE-n-EZ™ Membrane* over the substrate so that the sheet is at the lowest point of the roof, is wrinkle free and the side of the membrane with the "over-lap" markings is on the top side (high side of the sloped roof) of the sheet. The membrane should overhang the perimeter of the roof by at least 3" (inches).
- Chalk a line at least 3" up from the lower edge of the membrane that can be used as a guide on the roof perimeter and assure this first roll is installed parallel to the roof edge. Position the membrane over the substrate and allow to relax.
- It is a good idea to use duct tape to secure the membrane at the top side of the sheet to insure the membrane does not move and has the chalk line evenly aligned with the roof edge. Fold the lower half of the membrane back onto itself exposing the substrate.
- Remove the plastic release paper from the lower half of the sheet.
- Fluff air under the sheet and mate the membrane onto the substrate starting in the middle of the panel working out to both edges or sides to minimize wrinkling of the panel.
- With a stiff broom, broom the fully adhered portion of the sheet to insure 100% adhesion with the substrate.
- Roll the adhered surface with a steel linoleum roller that is weighted to 50 pounds per sq inch.
- Remove the duct tape from the upper half of the membrane panel and fold back the remaining un-adhered portion of the sheet toward the roof's edge. Follow proper safety procedures to avoid a fall from the roof edge.
- Remove the plastic release paper from the upper half of the sheet. While facing the roll and the roof edge, kneel and starting in the middle of the sheet, pull the sheet toward you, working out and to the edges avoiding wrinkles.
- Broom and roll the entire sheet to insure 100% contact.



Water Tight Technologies, LLC

P.O. 899, Payson, AZ 85547

www.britenez.com

Product Data Sheet

BRITE-n-EZ™ TPO Membrane Self Adhered

.060" (60 mil) and .045" (45 mil)

SUBSEQUENT SHEETS:

1. There should be a minimum of 3" overlap on previously installed sheets for subsequent sheets. It is useful to mark the previously adhered sheet with a water soluble roofing crayon 3" down from the top of this sheet. This will be used as the starting point for the bottom of subsequent sheets.
2. Align the sheet on the substrate, assuring the sheet is parallel to and aligned with the required 3" overlap on the prior sheet. Be certain the edge of the roll without pre-applied adhesive overlaps the prior roll. Duct tape this sheet to the previously adhered sheet to assure the sheet does not move.
3. Fold the upper half of the membrane back onto itself exposing the substrate.
4. Pull the release paper from this half of the sheet taking care not to let the top side of the plastic release paper contact the adhesive.
5. Stand or kneel at the center of the bottom half of the sheet – making sure it is still properly aligned with the previously adhered sheet. Fluff air under the sheet with adhesive and slowly push the membrane onto the substrate. Work from the middle out to both edges or sides to minimize wrinkling of the panel.
6. Broom and roll the membrane upper half of the membrane panel and then fold back the remaining unglued portion of the sheet. Mark the bottom side of the sheet 3" in from the edge as a guide for setting seam tape (this should be void of adhesive and release paper).
7. With a *BRITE-n-EZ™ Scrub Pad*, apply *BRITE-n-EZ™ Tape Primer* from the edge of the seam in to the 3" mark using a back and forth motion. Let the primer dry.
8. Partially unroll a roll of *BRITE-n-EZ™ Seam Tape* and set the tape on the back side of the panel being adhered with the backing paper aligned with the 3" mark on the back of the membrane. It is important that *Seam Tape* is exposed beyond the end of the membrane panel. With your hand, rub the tape to insure good contact with the membrane. Do not remove the seam tape backing paper at this time.
9. Apply *BRITE-n-EZ™ Tape Primer* to the 3" overlap area on the sheet previously installed with a *BRITE-n-EZ™ Scrub Pad*. Take care not to walk in the area just primed and be sure primer has dried.
10. After the primer has dried, pull the plastic release liner from the sheet and push in the direction of the previously installed sheet to initiate contact with the substrate.

11. Pull the release paper from the seam tape at 45 degree angle while brushing the seam with your hand to insure even contact with seam lower sheet.
12. Broom and roll the entire sheet to insure 100% contact.
13. With firm pressure, roll the seam area with a *BRITE-n-EZ™ Hand Roller*, traveling both lengthwise and then across the seam.

Product Data:

Available Sizes: 5' x 50' rolls
10' x 50' rolls
5' x 100' rolls
10' x 100' rolls

Carton Sizes: Sold by individual rolls

Storage: Store in original, opened packaging and away from sources of puncture and physical damage. Store rolls on their sides on pallets or shelving.

Assure that structural decking will support the loads incurred by the material stored on the roof. The deck load limitations should be specified by the project designer.

Shelf Life: Not Applicable

Precautionary Data:

To avoid sources of punctures and physical damage, take care when moving, transporting or handling.

All rough substrate surfaces which could damage the membrane should be repaired as specified to offer a smooth substrate.

All substrate surface voids greater than 1/4" (6.35 mm) wide shall be properly filled with an acceptable material.

Waste products such as petroleum products, greases, animal fats, and oils (mineral and vegetable) should be isolated from the membrane. Membrane rolls are heavy. Position and install by at least two people.

Refer to Material Safety Data Sheet for additional information.